

Taking A Mold Using a Foam Impression Box

!!! DO NOT SIMPLY STEP INTO THE FOAM* !!!

*This will cause too much of a collapse in the foam for the arch area

STEP 1: *Place your foot directly on top of the foam in the center. There should be about a 1" margin.*

STEP 2: *Ensure that your leg is at a 90° angle.*

STEP 3: *Place both hands on top of your knee, lean slightly forward and push down (from heel to toe).*

STEP 4: *Slightly rock your foot towards the outside.*

STEP 5: *Close the used side and repeat the steps for the other foot.*



For any questions or concerns, please contact:

TeleHealth Care Coordinator:

Tiffany Hung, CFO, CFts

(714) 932-3133 | telehealth@4activelife.com